



Revised 30th November 2015
14th October 2010

Vacuuming To Waste Instructions

Top up pool water if the pool is very dirty as you will be vacuuming to waste and the pool water level cannot be below the skimmer basket at any time during vacuuming.

1. Attach vacuum hose to vacuum head.
2. Fill up your vacuum hose with water either from garden hose or by submerging in pool. This is to ensure no air bubbles get sucked into vacuum head. Leave vacuum hose in pool so it stays full of water.
3. Place vacuum hose into skimmer box at end of pool.
4. Turn M.P.V on sand filter to waste position and open valve on backwash line.
5. Turn on pump at switch. Pool is ready to vacuum. Note keep an eye on pump to ensure it does not run dry.
6. If pool is very dirty the skimmer basket and pump lint pot will fill up quickly. If one or both are full turn off pump at switch, leave vacuum head in pool and empty both baskets. Turn pump on at switch and resume vacuuming. Keep eye on pump in case it runs dry due to an air bubble.
7. When finished turn off pump at switch. Remove vacuum hose and head. Ensure the M.P.V is turned from waste to filter. Close the valve on backwash line.

Never move M.P.V on the sand filter if the pump is running.