



A.C.N. 005 363 833

Amended 19.2.2019  
Amended 6.12.2017  
November 2015

### Shock and Floc Treatment – CARTRIDGE FILTERS.

	<b>30 - 50 M<sup>3</sup></b>
<b>PRODUCT</b>	<b>HEAVY DISCOLOURATION OR HEAVY ALGAE</b>
<b>DRY ALKALI</b>	5 Kg
<b>FAST FLOC</b>	5 Ltr
<b>CALCIUM HYPOCHLORITE</b>	2 Kg

- 1) Add Poolkare Dry Alkali by dissolving in a plastic bucket of water and pour around pool returns.
- 2) Add Chlorine at this step. Dissolve in plastic bucket of water and pour around pool return.
- 3) Fill pool as much as possible. Shake bottle of Poolkare Fast Floc and add 2.5 Ltrs one at a time in a plastic bucket of water and pour around pool returns.
- 4) Remove cartridges from filter and recirculate for 4 -6 hrs.
- 5) Check pH level it must be between 7.2 – 7.6. If pH below 7.0 add 1/10 dose of Dry Alkali. If pH above 7.8 add 1/10 dose of Fast Floc.
- 6) Allow pool to settle overnight.
- 7) Vacuum to waste next morning.
- 8) Return cartridges to filter after vacuuming pool.
- 9) If pool water is discoloured check pool levels of pH (7.2 – 7.8), Alkalinity (120 -200 PPM) and Free Cl > 6ppm. If any of the above levels are out of range adjust as necessary, OR bring in sample for testing.
- 10) If pool remains cloudy after steps contact manufacturer.

**Cartridge filters:- these must be by-passed or removed before any recirculation occurs.**  
**Check all isolation valves are in correct positions before removing cartridges or bypassing water.**  
**Please call on the numbers below if further assistance is needed.**



18 Embrey Crt Pakenham Vic 3810  
Ph: (03) 5940 1077 Fax: (03) 5940 2599

